

- 1. DRAIN PIPES BELOW THE BASE MAY BE NECESSARY IN SLOW DRAINING SOIL SUBGRADE.
- 2. BASE THICKNESS VARIES WITH TRAFFIC, CLIMATE, AND SUBGRADE CONDITIONS. COLDER CLIMATES AND WEAK SOILS MAY REQUIRE THICKER BASES. CONSULT ICPI TECH SPEC 4 TO DETERMINE BASE THICKNESS.
- 3. CONSULT ICPI TECH SPEC 2 FOR GUIDELINES AND SPECIFICATIONS FOR BASE MATERIALS, SUBGRADE SOIL AND BASE COMPACTION.
- 4. DO NOT COVER ENTIRE TOP OF AGGREGATE BASE WITH GEOTEXTILE.



STREET / PARKING LOT ON COMPACTED AGGREGATE BASE

DRAWING NO.

ICPI-04

SCALE

NO SCALE