

NOTES:

1. USE CONCRETE HEADERS AT TOP AND BOTTOM OF SLOPE OR WHEN CHANGING SLOPE ANGLES. DO NOT USE INTERMITTENTLY SPACED CONCRETE HEADERS.



HEADER FOR HIGH SLOPE WALK/ RESIDENTIAL DRIVEWAY DRAWING NO.

ICPI-76

SCALE

NO SCALE